

Schablone zur Ermittlung der Kettenlinie beim Bafang BBS01 und BBS02 Motor

Hierbei ist der Versatz und Durchmesser (=Länge der Linie) des jeweiligen Kettenblatts ersichtlich. Wir empfehlen die Schablone auszuschneiden und die "Achse" im Innenlager (vorher ausbauen) zu platzieren.

Somit ist erkennbar, welches Kettenblatt bei deinem Bike passt (Kettenlinie) und ob Kettenblatt und/oder Motor die Schwinge berühren (Spacer verwenden).

**Bafang BBS01 ans BBS02
Template to check chainline**

**FASTER
BIKES**

33.1 mm

12 mm Lekkie 40T (1604-40T)

10 mm Lekkie 42T (1604-42T) + 46T (1604-46T)

7 mm Lekkie 52T (1604-52T)

5 mm Original Bafang 46T (1602)

0 mm

Lekkie 28T (1604-28T)

Lekkie 36T (1604-36T)

Luna Mighty Mini (30T, 1612-7)

START

In this document you can see offset and diameter (= length of line) of our different chainrings. We recommend to cut out and place the "axle" inside your bottom bracket (remove before).

This way you can see which chainring fits your bike (chainline) and whether chainring and/or motor touch your bike frame (spacers needed).

